

ESTHERVILLE UNIVERSAL REMOTE

USE THIS REMOTE IN CONJUNCTION WITH YOUR ESTHERVILLE TV SET TOP BOX

SYSTEM ON/OFF
Power on/off up to five components with one button

POWER
Turn your TV, AUD, DVD, AUX & Cable Box on and Off

MENU
Displays the Applications Menu

GUIDE
Displays the program guide listings

OK/SELECT
Selects highlighted screen options.

SETTINGS
Displays settings menu.

MUTE
Silences the audio. Press to activate. Press again to restore sound to the previous level.

VOLUME Δ / ∇
Raises or lowers the sound level.

FAV
Displays favorite channels.

DAY Δ / ∇
Skip forward or backward a whole day in the program guide.

REPLAY
Replays the previous few seconds of a program

LIST
Displays a list of programs you have recorded, allowing you to select one for viewing.

NUMBER PAD
Enter numbers to tune to channels. Also, make numeric entries on on-screen menus.

ON-OFF
Opens or closes the PIP window through the Cable STB.

VIDEO SOURCE
Selects a video source from available video components.

SWAP
Swaps the contents of the PIP window and the main viewing screen through the Cable STB so that the PIP window displays on the main screen.

LIGHT BUTTON
Press to backlight all keypad buttons. Press again to turn off (or simply wait 10 seconds for automatic shut-off).

AUX, DVD, AUD, TV, CBL
Device Buttons used to select the component you want to operate and signals remote control activity.

INFO
Displays information about the program currently playing or highlighted in the program guide.

EXIT
Exit from current screen.

PAGE +/-
Accesses pages above or below the information currently displayed.

CURSOR NAVIGATION PAD
Navigate to and highlight an item from the on-screen choices.

A, B, C, D
Make direct selection from on-screen menus.

CHANNEL Δ / ∇
Selects the next higher or lower channel.

LAST
Returns to the previously tuned channel.

LIVE
Displays live television programming.

VCR/DVD/VOD KEYS
Perform standard VCR and DVD functions when the VCR and DVD mode, and Video-On-Demand functions when the CABLE mode.

RECORD
Record current programming

ASPECT/#
Changes the HD screen viewing aspect ratio through the Cable STB.

PIP CH +/-
Selects the next higher or lower channel in the PIP window through the Cable STB.

MOVE
Moves the PIP window to another location on the screen through the Cable STB.

UR5L-9020L